

OME STONEGUARD KIT LONG

OME665

CONTENTS:

PART No	QTY	DESCRIPTION
5811058L	1	STONEGUARD – LONG L/H/S
5811058R	1	STONEGUARD – LONG R/H/S
6151289	2	BOLT M6 X 30 SQ ZP
6151162	2	NUT M6 X 1.0 NYLOC
6151046	2	WASHER M6 FLAT

Installation Procedure

1. Slip stoneguard over lower shock mount.
2. Position the lower clamping strap slightly above the weld line on the shock body.
3. Ensure the stoneguard is facing forward and securely tighten all bolts.

